

HIGH PERFORMANCE ECO-FRIENDLY PRODUCTS

FORMULA

909

SOY BASED SOLVENTS

ODORLESS  
HIGH FLASHPOINT  
BIODEGRADABLE  
\*CONTAINS 0 g/L VOC

SOYBEAN DEGREASER & MASTIC REMOVER BIODEGRADABLE



This Floor or Wall Covering Adhesive Remover contains less than 5% V.O.C. content by weight, in accordance with the requirements set forth by the California Air Resource Board (CARB) and Ozone Transport Commission (OTC), effective 1-1-2009.

5 Gallons (18.927L)



PRODUCT DESCRIPTION

SENTINEL 909 SOYBEAN DEGREASER & MASTIC REMOVER is a biodegradable, soybean based solvent cleaner ideal for the removal of asphaltic mastics, adhesives, grease, lubricants, inks and other petroleum based residues. 909 is a safe alternative to hazardous and flammable solvents such as citrus, terpene, chlorinated solvent and petroleum.

WARRANTY NOTICE

Seller makes no warranty, expressed or implied, nor accepts any responsibility for any direct or consequential damages beyond purchase price, because seller cannot control user's handling, and use, or effect of that use.

WARNING

Sheet vinyl, vinyl or asphalt floor tiles and associated backings, mastics and other adhesives MAY contain asbestos, which is hazardous to health. Follow all local, state and federal regulations when removing adhesives containing asbestos.



WARNING

(Contains: Unsaturated methyl esters, 2-(2-butoxyethoxy) ethanol, Surfactant)

HAZARD STATEMENTS: Causes skin irritation. Causes serious eye irritation. PRECAUTIONARY STATEMENTS: Wash hands thoroughly after handling. Wear eye protection, protective clothing, protective gloves. IF ON SKIN: Wash with plenty of soap and water. If skin irritation occurs: Get medical attention. Take off contaminated clothing and wash before reuse. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do so. Continue rinsing. If eye irritation persists: Get medical attention. Dispose of contents/- container to licensed waste handling facility. FIRST AID NOT FOUND IN PRECAUTIONARY STATEMENTS: IF INHALED: Remove to fresh air and keep at rest in a position comfortable for breathing. Call a POISON CENTER or doctor/physician. IF SWALLOWED: Rinse mouth, do NOT induce vomiting. Obtain emergency medical attention. HANDLING AND STORAGE: Do not handle until all safety precautions have been read and understood. Wash hands and other exposed areas with mild soap and water before eating, drinking or smoking and when leaving work. Provide good ventilation in process area to prevent formation of vapor. Do not breath mists. Keep away from sources of ignition - No smoking. Keep only in the original container in a cool, well ventilated place away from: Heat sources. Keep container closed when not in use.

REFER TO SDS FOR MORE INFORMATION FOR INDUSTRIAL USE ONLY KEEP OUT OF REACH OF CHILDREN

FOR SPECIAL INSTRUCTIONS CONTACT SENTINEL'S CUSTOMER SERVICE AT 1-800-373-0633 OR VISIT US AT www.senpro.com



Sentinel Products, Inc.  
Brooklyn Park, MN 55445  
800-373-0633  
www.senpro.com

DIRECTIONS

Review directions and precautions thoroughly before starting work.

STEP ONE: Protect walls, cabinetry, trim, drains, cracks and adjoining flooring with plastic and/or absorbent dikes (oil absorbing powder, kitty litter, rags) to keep mastic remover and liquified adhesive contained as well as to protect from overspray or agitated material in subsequent steps.

STEP TWO: Apply 909 to the entire adhesive surface. Be sure to apply enough remover to completely penetrate and saturate the adhesive to be removed. Allow 909 to soak and penetrate for 40-60 minutes.

STEP THREE: Agitate the surface with stiff, short bristled brushes or coarse stripper pads. Squeegee or scrape the softened or liquified adhesive into puddles and solidify with an absorbent. Remove absorbed material to a container and dispose of following all local, state and federal regulations.

STEP FOUR: If necessary, reapply and repeat steps two and three.

STEP FIVE: Wash and rinse the floor thoroughly using Sentinel 317 Multi-Purpose Cleaner & Degreaser and water or a soap and water solution. Allow subfloor to dry for at least 24 hours and test moisture levels before reflooring.

